


Data Portal /Uplan Overview

Open Browser (Firefox or Chrome) and enter: data.udot.utah.gov



Create a bookmark: Ctrl + D (shortcut for Firefox and Chrome)

Firefox: Upper Right



Chrome: Upper Right



Ctrl + Shift + B will show the bookmarks bar in Chrome or show all bookmarks in Firefox

Click Download Data

Filter & Search

Category: -- All Categories --

Search: Search ... Catalog Data

Layers


Layer	Categories	Info	Data	Preview	KML / KMZ	Shapefile	All Formats
Cattle Guard Inventory	Asset , Maintenance	Info	Data		KML	Shapefile	3 Files
Shoulders Inventory	Asset , Maintenance	Info	Data		KML	Shapefile	3 Files
TIGS Projects	Project	Info	Data		KML	Shapefile	3 Files
Functional Class	Planning	Info	Data		KML	Shapefile	3 Files
Through Lanes	Planning	Info	Data		KML	Shapefile	3 Files
AADT	Planning	Info	Data		KML KMZ	Shapefile	4 Files
HOV	Planning	Info	Data		KML	Shapefile	3 Files
Urban Code	Planning	Info	Data		KML	Shapefile	3 Files
Facility Type	Planning	Info	Data		KML	Shapefile	3 Files
Ownership	Planning	Info	Data		KML	Shapefile	3 Files
Mile Posts	Reference	Info	Data		KML	Shapefile	3 Files
Highway Reference Features	Reference	Info	Data		KML	Shapefile	3 Files
Station Boundary	Maintenance	Info	Data		KML	Shapefile	3 Files
Long Range Plan	Planning	Info	Data		KML	Shapefile	3 Files
PM Workplan by section	Asset , Pavement	Info	Data		KML	Shapefile	3 Files

row(s) 1 - 15 of 62 Next

Click Main, Data Portal or Home to return to the Data Portal Page



Use Issue/Bug/Enhancement to report any issue with the Portal



Click UPlan




UPlan Home Page Tour

A screenshot of the UPLAN home page with several red annotations. At the top left, a navigation menu contains "HOME", "GALLERY", "MAP", and "GROUPS". A red arrow points to "HOME" with the text "GO HOME". At the top right, there is a "Sign In" link and a search bar. A red arrow points to the search bar with the text "SEARCH". The main content area features a large banner image of a bridge with the text "UPLAN UDOT MAP CENTER". Below the banner is a "FEATURED CONTENT" section, outlined in red, containing four thumbnails: "2012 AADT Map", "UDOT Access Inventory Map 2013", "UDOT Mile Posts Map", and "UDOT Fiber Gallery". Below this is a text block describing UPLAN and UDOT, with a "UDOT Data Portal" and "UDOT Home Page" link. A red arrow points to these links with the text "WEB LINKS". The UDOT logo is in the bottom right of this section.

BOTTOM OF PAGE

A screenshot of the bottom of the UPLAN page. It shows a disclaimer in small text: "and maintain accurate, complete, and timely information on this Web site. Neither the Utah Department of Transportation, the State of Utah, nor...". A red arrow points to the "Help" link in the footer with the text "ADVANCED HELP". The footer contains the following links: "Esri.com", "Help", "Terms of Use", "Privacy", "Contact Esri", and "Report Abuse".

Click UDOT Mile Post Map



Map Navigation

HOME ▾ UDOT Mile Posts Map

Details | Basemap

About | Content | Legend

Legend

MilePosts

- Mile Posts
- MilePosts - 50 Miles

UDOT LRS Routes

- LRS Routes
- Interstate
- US Route
- State Route
- Institutional Route
- Fed Aid Route
- Ramp - (Interstate, mainline)
- Ramp - (Interstate)
- Ramp - (US Route)
- Ramp - (State Route)

Share | Print | Measure | Find address or place

MODIFY MAP | Sign In

SEARCH

ZOOM IN/OUT

Esri.com | Help | Terms of Use | Privacy | Contact Esri | Report Abuse

UDOT GIS | UDOT | esri

NOTE:
To create and save maps you must have a UPlan account and must sign in

Layer Control is Hierarchical

The screenshot shows a GIS interface with a Layer Control panel. At the top, there are tabs for 'Details' and 'Basemap'. Below that are tabs for 'About', 'Content', and 'Legend'. The 'Contents' section lists various layers with checkboxes. A context menu is open over the 'Poor' layer, showing options for 'Show Table', 'Filter', and 'Description'. Red callouts provide instructions on how to interact with these elements.

Basemap Changing the Basemap can improve layer visibility

Content Content must be selected to manipulate layers

Maintenance Assets Only checked layers will be visible (Hierarchical)

Poor Click layer name to view symbol

Filter Click the small down arrow for more options (Show Table & Filter)

Show Table

Filter

Description

UtahBaseMap-Vector BaseMap is shown at the bottom

Tables and Filtering: Find all signs with poor condition for a particular maintenance station





Table Options



Access Filter Function
View and Zoom to Selections